

Congratulations on your purchase of this Sunpak tripod, made for your compact digital camera. It has been designed for many years of dependable service. Use this tripod and your camera's self-timer to step out from behind the camera and be included in your family pictures. You can also take steady, sharp closeups, great low light and nighttime scenics or indoor photos! Your new tripod's versatile "take anywhere" design and ultra-light weight make it the perfect companion for your digital camera or camcorder. You'll never want to be without it.

#### HOW TO USE THIS PRODUCT

Attach your camera to the tripod using the quick-release standard 1/4" X 20 threaded screw. Be sure to hold your camera securely when adjusting the tripod's legs and head. Make sure that the area to which your tripod will be secured is clean, dry and suitable to support the tripod and camera. **Maximum load capacity of 16 oz. for this tripod is dependent upon surface shape, texture, size and how it is used.**

To secure your tripod's legs to an object, take each leg of the tripod and wrap it around the item that you intend to mount, making sure that each of the rubberized rings on the tripod's leg segments makes contact with the object.

You can mount your tripod in any number of ways (see some examples below). Or, even use it as tabletop tripod. **Never mount the tripod upside-down!**



#### USE AND CARE OF YOUR TRIPOD

- This product is not a toy and is not intended for use by children.
- Use only with digital cameras weighing less than 16 oz.
- Not intended for use with heavy cameras, camcorders or cameras with long lenses, which will be unstable when mounted on this product.
- Maximum load capacity is 16 oz and determined by how the tripod is used.
- Maximum capacity determined by how legs are attached to surface.
- Confirm camera and tripod steadiness before releasing to ensure stability.
- Do not carry or transport the tripod with the camera attached.
- Do not oil or grease any part of the tripod, or use any solvents or thinners to clean your tripod. Use a little mild detergent on a soft, damp cloth and wipe dry with a soft, lint-free cloth.
- Do not store or expose your tripod to excessive heat, cold or moisture, or use close to any flame or fire. Store your tripod in a clean, dry place.

#### How to use your FlexPod Gripper's Quick-release system



1. Pull the Release Handle outwards and rotate the handle clockwise to unlock the Quick Release Post from the ball head's Quick Release Receptacle. Lift the Quick Release Post out.

2. Once it has been removed from the receptacle, screw the Quick Release Post into the bottom of your camera.

Then reinstall by mounting the post back into the receptacle. Turn the Release Handle counterclockwise and then push the Release Handle inwards to secure and lock the Quick Release Post back in the Quick Release Receptacle.

3. To adjust your camera in various positions, turn the Ball Head Lock Knob counterclockwise. You can utilize the Vertical Cut-out to set your camera to a vertical shooting mode. Once you have achieved your desired position, turn the Ball Head Lock Knob clockwise until secure.



## Limited Lifetime Warranty

This Sunpak product has been carefully manufactured, accurately adjusted, inspected and thoroughly tested before shipment to assure you of the highest quality.

Should this Sunpak product require service, we will repair or replace, at our option, any part, or the product itself, which our examination shows to be defective in material or workmanship. *This warranty does not apply to wear and tear associated with the normal use of the product.* This warranty is non-transferable.

Repairs will be made to the product at no charge, under the terms of the warranty as stated above, only when accompanied by a copy of your dated and itemized sales receipt.

Be certain to follow all assembly and/or operating instruction with this product. **This warranty is not valid if the product has been misused or damaged in any way that is beyond our control or through normal wear and tear associated with its use. This warranty only applies to the product and we are not responsible in any way for losses, damages or any inconvenience caused by equipment failure.**

Some states do not allow the exclusion or limitation of consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights and you may have other rights which may vary from state to state.

Should service be required, the product should be carefully packed and sent pre-paid and insured to the address listed below. A note briefly describing the nature of the defect should also be enclosed to expedite handling.

**Proof of purchase must be included for all warranty repairs.**

### OWNER'S RECORD

*Please complete this section and retain with your original sales receipt.*

Purchase Date \_\_\_\_\_

Dealer's Name \_\_\_\_\_

Address \_\_\_\_\_

City \_\_\_\_\_ State \_\_\_\_\_ Zip \_\_\_\_\_

### SPECIFICATIONS

Height: 7.25 in.

Weight: 3.8 oz.

Maximum Load Capacity: 16 oz.

**Note:** Maximum capacity determined by how the tripod is used.

Product design and specifications subject to change.

Sunpak  
ToCAD America Inc.  
53 Green Pond Road  
Rockaway, NJ 07866  
973-627-9600  
tocad.com

# Sunpak flexPod gripper

